

# INSTALLATION GUIDE SAGA

# **Follow These Steps:**

- **1.** Draw a level line on the wall to mark the top row and the center.
- 2. Repeat for each row underneath (10.5 cm / 4.13 inches in between).
- **3.** Apply a line of construction adhesive about 2-3 cm / 1 in below the bottom line.
- **4.** Push tiles against construction adhesive, starting from the center and moving outwards.
- **5.** Repeat for each row and continue upwards. Let completed installation dry for 24 hours.


### The ending will differ depending on the number of rows.

- 6. Ending with even row number.
- 7. Ending with odd row number.


## How to Calculate the Total Height of Installation


**8.** Length of bottom row tile shape + number of rows above x 4.1", rows are 4.1" apart (same row distance for all shapes), 80 x tiles cover 1m2 (7.4 tiles / sqft)


For more information on Saga, visit <u>scandinavianspaces.com/products/saga</u>






















# INSTALLATION GUIDE SAGA

